cabrio
lighting series
by EasyPro Pond Products

Cabrio Color Changing Remote Control
Instructions for Operation · Safety · Warranty

Thank you for purchasing EasyPro's Cabrio color changing remote control. With this remote you can sync multiple Cabrio fixtures together, change modes, brightness and speed. Control your Cabrio LED lights to illuminate a pond or waterfall, highlight a deck or patio and extend the enjoyment of your entire landscape in the evening hours.

Remote Operation

- A single remote can operate multiple Cabrio fixtures in any combination within its range.
- Depress mode, brightness and speed buttons **slowly and deliberately** to ensure all light fixtures remain in sync on the same cycle.
- Desired setting must be achieved by clicking remote functions, holding a button down will not change settings.
- The LED light will default to mode 1 on initial startup.
- CLEDRC remote requires an A23 battery (included).

Power on/off
Slower Speed
Lower Brightness
Change Mode Backwards
Red (mode 21)
Blue (mode 23)

Reset Defaults (mode 1)
Faster Speed
Raise Brightness
Change Mode Forwards
Green (mode 22)
White (mode 27)

A23 battery included

Color Modes

1. Fade — Red, Green, Blue, Yellow, Purple, Light Blue, White
   • Fades into listed colors (default mode)
2. Change — Red, Green, Blue, Green
3. Change — Red, Green, Blue
4. Change — Blue, Green, Red
5. Change — Red, Green, Blue, Green
   • Four color cycle accelerates to strobe
6. Change — Red, off, Green, off, Blue, off, Yellow, off, Purple, off, Light Blue, off, White, off
7. Change — Yellow, Pink/Purple, Light Blue
8. Change — Red, Yellow, White, off
9. Change — White, Yellow, Red, off
10. Change — Red, Green, Blue, Yellow, Purple, Light Blue, White
11. Solid — Pink
12. Solid — Yellow
13. Solid — Green/Yellow
14. Solid — Aqua
15. Solid — Sky Blue
16. Solid — Electric Blue
17. Solid — Blue/Purple
18. Solid — Purple
19. Solid — Hot Pink
20. Demo Mode
    • Scrolls through modes 1-10, beginning with mode 10, 1, 2, 3...
21. Solid — Red
22. Solid — Green
23. Solid — Blue
24. Solid — Yellow/Green
25. Solid — Purple/Pink
26. Solid — Light Blue
27. Solid — White

Brightness Settings

Dimmest ... Brightest

1 — off
9
18 — default

Speed Settings

Slowest ... Fastest

1
8
default
15

EasyPro™
pond products